



MAXI-BUTYL FLASHING TAPE INSTALL GUIDE



Scope

Used to flash around framed joinery openings as a secondary weather resistant barrier. Used at joinery heads to seal flashing upstands to wall underlay. Suitable to use around approved Rigid Air Barriers systems joinery openings and sheet joints.

Conditions & Limitations

MAXI-Butyl Flashing Tape must be installed in accordance with the specifications and latest technical information and must comply with all relevant clauses of the NZBC regulations and standards. MAXI-Butyl Flashing Tape is UV stable for 180 days. Caution when bonding onto waterproofing membranes, coatings and substrates. Always confirm suitability with the substrate supplier.

Applicable to 150mm & 200mm rolls

- Cut the underlay at a 45° angle away from each corner, into the centre. Fold the flexible underlay back to the inside face of the framing, keep taut and secure.
- Cut four butterfly pieces of MAXI-BUTYL Tape @ 150 x 50mm.
- Apply two butterfly pieces at 45° angle to the two bottom corners. Overlap the sill & jamb junction by 3mm to create a seal at the junction.
- Measure the width of the sill and add 400mm. Cut a piece of MAXI-BUTYL Tape to this length.

Applicable to 150mm & 200mm rolls “Continued”

- Mark 200mm up each jamb. Remove 50mm of the release film off the back face of the MAXI-BUTYL Tape. Position the tape flush with the inside of the frameline @ the 200mm mark on the jamb. Remove release film and apply the tape down the jamb, tight into the sill / jamb junction, across the sill and up the opposing jamb by 200mm.
- Cut the MAXI-BUTYL Tape at the corners away from the frame. The overhanging tape is folded onto the face of the underlay.
- Cut 2 pieces of MAXI-BUTYL Tape @ 400mm. 200mm is installed down the jamb, 200mm to the underside of the lintel. The two remaining butterfly pieces are applied last to each corner of the jamb / lintel junction at a 45° angle with a 3mm overlap.
- Ensure all tape is pressed firmly onto the underlay to ensure proper adhesion

Applicable to 75mm MAXI-BUTYL

- 75mm MAXI-BUTYL may be used as a head flashing tape, used to form butterflies at corners, a sealing tape onto selected Rigid Air Barriers.
- Ensure tape is pressed firmly onto the substrate to achieve adequate adhesion.
- Please refer to the relevant suppliers specifications before installing any MAXI-BUTYL.

Marshall Innovations accepts no responsibility or liability for the incorrect installation of this product. Always check for compatibility between tapes and substrates.

Handling and Storage

MAXI-BUTYL must be stored in a cool location, under cover and out of direct sunlight. No stacking on the tape to prevent damage and roll deformation.



General Notes

- Installation must be installed in accordance with MAXI BUTYL installation guide and the WANZ Guide to Window Installations.
- Must be covered within 180 days of installation.
- Always ensure the substrate is clean and dry and free of any contaminants
- Compatible with most sealants, always check suitability with sealant manufacturer.
- Always check specifications and compatibility over waterproofing membranes and Rigid Air Barriers.
- Can be installed in extreme temperatures from 0 to 80°C
- No primers required
- Easy to install with split release liner
- Visit www.mwnz.com for full details on product, installation, application and relevant standards.

